

# INSULATION LIDS FOR CONTAINERS

## DATASHEET & USER GUIDE

### Intended use of the product

This datasheet is valid for all our standard and custom container insulation lids, with or without openings, unless stated otherwise. The lids are intended to keep the top of containers insulated and protect them from direct sunlight.

For industrial use only. If used in combination with any type of heating equipment, that equipment must be operated by personnel trained in heating equipment safety. Not intended for household use or for covering living beings.

### Disposal of the product

Refer to local rules and regulations for detailed information on how to dispose of the lid.

Use the material list below, along with information about any chemicals that may have been in contact with the cover, to determine the correct disposal method.

### Materials

- Fabric and insulation (depends on lid colour):
  - Black Cordura (Nylon 6,6 - flame-retardant, highly durable) & polyester insulation.
  - Grey (silver) or white silicone-impregnated glass fibre fabric (Very high temperature resistance) & glass fibre insulation. The white silicone impregnated fabric is FDA approved for foodstuff and pharmaceutical use.
  - Coloured or grey nylon fabric & polyester insulation (not shown in the images).
- Polyester sewing thread.
- Glass fibre fabric.
- Nylon Velcro.

### How to use

- Mount onto the appropriate container size and shape.
- May be used with heating jackets, insulation covers, base heaters and similar heating devices, provided the temperature does not exceed the lid's maximum operating temperature, and the heating device is approved for use with lids.
- Clean and dry between uses to prolong product lifespan.
- Avoid sharp folds and prolonged exposure to direct sunlight when storing, to prevent material cracking.

### Environment

Ambient and operating temperatures:

- Coloured or black versions: -10°C to +100°C
- Grey or White versions: -10°C to +200°C

### Language

This datasheet was originally written in English. Scan the QR code for other languages or to check for updated versions.

