

PVC COVER FOR CONTAINER

DATASHEET & USER GUIDE

Intended use of the product

This datasheet is valid for all standard and custom container PVC covers, with or without a window, unless otherwise specified.

The covers are intended to keep the top and sides of containers dry and protected from direct rain and sunlight.

For industrial use only. If used in combination with any type of heating equipment, it must be operated by trained personnel familiar with heating equipment safety. Not intended for household use or for covering living beings.

Disposal of the product

The product consists primarily of PVC and can typically be disposed of as hard plastic waste.

Refer to local rules and regulations for detailed information about how to handle disposal of the PVC cover.

Use the material list below, along with information about any chemicals that may have been in contact with the cover, to determine the correct disposal method.

Materials

Materials used in the construction:

- Blue PVC
- Transparent PVC film (window)
- Polyester sewing thread

How to use

- Mount onto the appropriate container size and shape.
- May be used in combination with heating jackets, base heaters, or similar heating devices, provided the temperature does not exceed the cover's maximum operating temperature, and the heating device is certified for use with covers.
- Clean and dry between uses to prolong product lifespan.
- Avoid sharp folds and prolonged exposure to direct sunlight when storing, to prevent material cracking.

Environment

- Ambient temperature range: -29°C to +70°C
- Operating temperature range: -29°C to +70°C

Safety

- Made from flame-retardant materials
 - Blue PVC: ISO 3795 (<100 mm/min)
 - Transparent PVC: French M2 classification

