

Technical data sheet

OEL-KLEEN Oberflächenpower

Properties:

Universally applicable liquid cleaning agent for deep cleaning of mineral, plant, animal, oil and grease stains from all types of flooring in rooms, open spaces, road surfaces and squares (except textile coverings). Neutral towards asphalt! OEL-KLEEN Surface Power is easily biodegradable.

Application/Dosage:

Water-soluble and suitable for machine cleaning! The recommended concentration for normally soiled floors is 10 ml per litre of water and, in extreme cases, 100 ml per litre of water.

Ingredient information:

≥5 - <15% soap, <5% EDTA and its salts.

Specification:

Density (g/cm³): 1.011

Colour: Beige

pH value: 11.4

Odour: Characteristic

Storage instructions:

Store in a frost-free place. Protect from direct sunlight. Can be used for at least 3 years if stored properly.

Environment:

The surfactants contained in this mixture meet the biodegradability requirements set out in Regulation (EC) No 648/2004 on detergents.

Dangerous goods:

Not dangerous goods

Labelling:



Warning H315 Causes skin irritation. H319 Causes serious eye irritation.

The information is based on our current knowledge and experience.

The technical data sheet describes products in terms of their chemical composition.

The information does not constitute a guarantee of properties.

Revised on: 18.11.2025