



IBS special cleaner WAS 60.100

SKU: 60.100

Alkaline high-performance concentrate. For the removal of heavy gumming and coarse soiling (resins, bitumen, tar, adhesions, encrustations, burnt-in/dried-in dirt). For application by wiping, spray cleaning (ideally suited for pre-spraying).

Applications:

- Spray cleaning
- Wiping method
- Very well suited for pre-spraying

Fields of application:

- Garden, agricultural and forestry equipment
- Power saws (cutting set: saw chain, guide bar)
- Saw blades, cutting tools (hedge trimmer, power scythe, lawn mower)
- Tool and machine housings
- Wood processing (harvester, circular saw, planer).

Soiling:

- Tree and grass resin.
- Bitumen, tar
- Incrustations and dried-on, burnt-in dirt
- Oil and fuel residues
- Other organic residues

Dosage

The product is a concentrate that must be diluted with sufficient water.

Our recommendation for the dosage:

- Light to normal soiling 3 - 10% or 1:20
- coarse to heavy soiling 10 - 20% or 1:10

Advantages

- Specially developed for effortless cleaning of heavy gumming and coarse soiling
- Effective with high cleaning power
- Gentle on materials, ideal for plastic and painted surfaces
- strong action for pre-cleaning
- silicone-free
- Environmentally friendly and user-friendly, surfactants readily biodegradable (according to OECD criteria)

Applications/areas of use

Technical data

Container size:	20 L, 200 L, 1000 L
PH value:	>13
Colour:	yellowish
Smell:	mild - characteristic
Foaming behaviour:	foaming
Application concentration:	5 -20%
Operating temperature:	Room temperature
Density:	1.03 g/cm ³
Labeling:	GHS05